

INCLUDED

- 18650 battery x 1
- Battery charger x 1
- Spare O ring x 1
- Tail cap/handle lubricant x 1

SPECIFICATION

Material: Anodised aircraft 6061 aluminium

Colour: Silver/grey

LED: 1x CREE XM-L2

LED lifespan: 100000 h

Brightness: 800 lm

Light colour: White

Mode: High/dimming

Battery: 18650 3.7 V, 2200 mAh







Switch design: Magnetic slide switch

Lens: Coated glass lens

Size: 147 x 35 mm (length x head diameter)

Weight (torch): 153 g


Weight (torch and batteries): 197 g

STANDARD	HIGH POWER	MID POWER	LOW POWER
	800 LUMENS	80 - 800 LUMENS	80 LUMENS
	1.5 hours	1.5 - 24 hours	24 hours
	500 m (beam distance)		
	20000 cd (peak beam intensity)		
	1 m (impact resistance)		
	100 m (depth rating)		

NOTICE

This data may vary depending on environmental conditions.

STRUCTURE



WARNING

1. The battery must be inserted positive end first. Do not insert the battery the wrong way.
2. Do not use different batteries to the one provided.
3. Do not use the battery if it is damaged.
4. When storing the torch, unscrew the handle or the tail cap to ensure the power is cut off.
5. After every dive, clean the torch with fresh, clean water and dry prior to storage. Salt water residue can corrode the torch surface.
6. Ensure that the tail cap and handle are lubricated regularly. A container of lubricant comes with your torch.
7. Avoid any impact on the glass lens.
8. Do not shine the light directly into eyes.

BATTERY INSTALLATION

Open the torch by unscrewing the handle or the tail cap by hand. Insert the battery positive end first (facing the switch), taking care not to disturb the O rings. Do not insert the battery the wrong way. Reclose the torch.

OPERATION

The torch is operated by the top-mounted slide switch. Use this to vary the torch output.

CHARGING

Your charger comes with instructions.

Ensure that you read and understand them prior to use.

WARRANTY

1. Your torch is covered by a full 12 month warranty.
2. If a fault occurs within 14 days due to a manufacturing defect, your torch will be replaced (proof of purchase required).
3. After 14 days and within 12 months of purchase, your torch will be repaired or replaced (excludes accidental damage or damage caused by misuse).
4. Outside the 12 month warranty period, your torch will be repaired at cost (if repairable).
5. In all cases, inward and outward shipping will be the customer's responsibility.

The warranty does NOT cover the following:

1. Damage caused by disassembly or modification.
2. External cosmetic damage caused by normal use or misuse.
3. Damage caused by incorrect battery insertion or battery leakage.

If you have any queries, please contact your local Northern Diver distributor. Alternatively, feel free to contact us. Our contact details are below.